
HARDWAX OIL MAINTENANCE OIL USE & APPLICATION



Rubio Monocoat Maintenance Oil is a ready-to-use product that was developed to care for hardwood and bamboo floors finished with Rubio Monocoat Oil Plus. This treatment restores and intensifies both the colour and the durability of the floor. Intervals for maintaining the floor vary according to how much wear the floor is getting. It is recommended that this treatment be carried out just before the existing oil finish shows signs of fading.

INSTRUCTIONS:

No professional expertise is required to treat your floor with Rubio Monocoat Maintenance Oil.

1. Eliminate dirt and dust from the floor.
2. Clean the floor thoroughly with Rubio Monocoat Soap and water. Rinse well with water to eliminate any soap residues. Leave it to dry completely.
3. Apply Rubio Monocoat Maintenance Oil with a cloth, a brush or a sponge, preferably in sections of 20 – 40 square feet at a time. Each treated section should be wiped dry with a paper towel within 15 minutes. If a floor polisher is used, carry out this treatment using a lint-free cotton cloth.
4. Ensure the room is well-ventilated. The floor should be dry after 6 - 8 hours.
5. The floor can be cleaned with a cloth dampened with water after 48 hours. Do not use soap at this stage! Wait 1 week before once more maintaining the floor with a mixture of Rubio Monocoat Soap and water

COVERAGE:

Each half liter can of maintenance oil will cover 800 – 1,000 square feet of flooring—depending on wear. Use very little product to prevent the floor from becoming sticky.

STORAGE:

The product can be stored for up to 12 months. Store in dry conditions and in the original packaging.

WARNING:

The product may NOT be diluted! Cloths, saturated with oil, may spontaneously combust. After usage, they need to be soaked in water before disposal.